


Table of contents


- Feeding supply unit XVE

Feeding supply unit XVE

Feeding supply unit XVE



Supply unit



1) Mains input with rectifier  
 2) Integrated braking transistor/braking resistor  
 3) Optional external braking resistor  
 4) DC bus capacitors  
 5) DC bus connection

XVE type code

Short type designation	1	2	3	4	5	6	7	8	9	1	1	2	3	4	5	6	7	8	9	1	1	2	3	4	5	6	7	8	9	4
										0										0										0
Example:	X	V	E	2	-	W	0	0	7	5	A	R	N	-	0	1	A	E	T	N	N	N	N	N	N	N	-	S	0	3
	①						②	③			④	⑤	⑥			⑦	⑧	⑨	⑩	⑪	⑫		⑬	⑭	⑮	⑯	⑰	⑱	⑲	
①	<b>Product:</b> 1: X = ctrlX DRIVE 2: V = Supply unit 3: E = Feeding 4: 2 = Generation 2																													
②	<b>Cooling type:</b> W = Air, internal																													
③	<b>Rated power:</b> 0030 = 30 kW 0075 = 75 kW 0125 = 125 kW																													
④	<b>Degree of protection, input voltage:</b> A = IP20, 3 × AC 380 ... 500 V +10% -15%																													
⑤	<b>Other design:</b> R = Integrated braking transistor and braking resistor																													
⑥	<b>Connector set:</b> N = Without																													
⑦	<b>Control section:</b> 01 = ctrlX DRIVE 02 = ctrlX DRIVE <sup>plus</sup>																													

missing-translation(boschrexroth.label.page) 2